



Spoke nipple dimensioning

- G = Thread
- K = Square shaft
- D = Shaft diameter (not width across flats)
- L = Total length